


E.X.DR.Z0



Xesar











Montageanleitung | Assembly manual | Montagehandleiding
Instructions de montage | Istruzioni di montaggio | Montážní návody
Montážne návody | Instrukcje montażu | Installationsanvisningar










E.X.DR.ZO.U.

W

L







x = 40–50 mm

2 x 40 mm >>>



x = 50–60 mm

2 x 50 mm >>>



x = 60–70 mm

2 x 60 mm >>>



x = 70–80 mm

2 x 70 mm >>>



x = 80–90 mm

2 x 80 mm >>>




x = 90–100 mm


2 x 90 mm >>>




1




2





3




Ø 8 mm




4








1





2




3




4





5




6




7




8





9



10



11



12



CHECK

