




E.X.BE.ZU.BS01




Xesar


Montageanleitung | Assembly manual | Montagehandleiding
Instructions de montage | Istruzioni di montaggio | Montážní návody
Montážne návody | Instrukcje montażu | Installationsanvisningar



1x



1x



1x

1x









1x









1x

1x







1




1

← Ø 14 mm 2

← Ø 8 mm 3

← Ø 10 mm 4




2




1


2




3



4




← Ø 14 mm 1







← Ø 8 mm 2

← 3
Ø 10 mm +
Ø 14 mm ↓ 2mm




5







3



4



5

