







E.X.PZ.HZ-S
E.A.PZ.HZ-S









Xesar & AirKey



Montageanleitung | Assembly manual | Montagehandleiding
Instructions de montage | Istruzioni di montaggio | Montážní návody
Montážne návody | Instrukcje montażu | Installationsanvisningar






1




IP65 ✓




max. 0,5 Nm




2




1




2





3




3




IP65




4





1




60°



2






5



2

1

40°




3

max. ~ 60°




6




1

AirKey

Xesar





2





3


CHECK



7



1





2

AirKey

Xesar

1





NEW

8





max. 4 Nm



9



CHECK



1

AirKey

Xesar

NEW



max. 5 s





10

AirKey



<https://airkey.evva.com>

Xesar



CE UK UK
NI CA



www.evva.com

EVVA Sicherheitstechnologie GmbH | Wienerbergstraße 59-65 | A-1120 Wien