



E.X.PZ.A0V
E.A.PZ.A0V




Xesar & AirKey

Montageanleitung | Assembly manual | Montagehandleiding
Instructions de montage | Istruzioni di montaggio | Montážní návody
Montážne návody | Instrukcje montażu | Installationsanvisningar




1x



1x



1x





2x

CR2




1x



cam supplied
by reseller



PH0 + PH2



E.ZU.PZ.ZW01



E.X.IM.CC

E.A.IM.SH.J80K+D08K






E.A.IM.KA.J80K+D08K













NEW



FZG




1





IP65 ✓




0,5 Nm




3x




2




1



2




3






IP65




3




0,3 Nm



4



1





60°




2

!



-5x


5



2

1

40°




EVVA

!




3



max. ~ 60°



6





1

AirKey Xesar





2



3




CHECK





7



2





1





3

AirKey Xesar




8



9




CHECK



10



Xesar



<https://airkey.evva.com>

CE UK UK
NI CA



www.evva.com

EVVA Sicherheitstechnologie GmbH | Wienerbergstraße 59-65 | A-1120 Wien